

EQUIPMENT

Power Supply Battery Preventative Maintenance

Preventive Maintenance

- Regularly (ideally every 6 months) check for faults, leaking, and corrosion.
- Do not store in extreme temperatures.
- When using an alternative source of power in the device, remove the batteries.
- For secondary batteries:
 - Do not let batteries discharge past their lower voltage limit
 - Check devices with secondary batteries every 6 months and perform discharge overnight test.