

Scales (Digital) Preventative Maintenance

Preventative Maintenance

- Regularly check and replace batteries
- Check power cord for defects
- Check calibration regularly
- Check for levelness
- Ensure that device is free of debris, corrosion, dirt, etc.